


# NEWALL

PART NUMBER CONFIGURATION FOR  
**MHG-VP**  
SERIES INCREMENTAL LINEAR ENCODERS



**THIS ENCODER CAN ONLY BE USED WITH THE SCC 200 MODULE SUPPLIED**

**STANDARD SPECIFICATIONS SHOWN IN RED**

## Measuring Lengths

50 mm  
75 mm  
100 mm  
125 mm  
150 mm  
175 mm  
200 mm  
225 mm  
250 mm  
275 mm  
300 mm  
325 mm  
350 mm  
400 mm  
450 mm  
500 mm  
550 mm  
600 mm  
650 mm  
700 mm  
750 mm  
800 mm  
850 mm  
900 mm  
950 mm  
1000 mm

- Always order by measuring length (MHG overall length = measuring length + 173 mm)
- Prefix the measuring length with 0's as necessary to get to a 6 digit order code. Example: 50 mm is 000050
- Linear Encoders include reader head with cable, scale (tube) and SCC 200 module
- Extension cables are sold separately
- Bracket kits to mount the reader head and scale are sold separately

### **Standard Brackets**

<i>Part Number</i>	<i>Description</i>
MHBKITSTD	MHG Scale Bracket Kit
600-65620	MHG Head Bracket Kit (Universal)
600-65340	MHG Single-End Bracket Kit

### **Lathe Kits (Includes Scale Brackets)**

<i>Part Number</i>	<i>Description</i>
600-81880	Heavy Duty Lathe Kit (MHG Cross / SHG Bed Axis)
600-65520	Lathe Kit (MHG Cross / SHG Bed Axis)
600-65500	Lathe Kit (MHG Single End Cross / SHG Bed Axis)
600-65510	Lathe Kit (MHG Single End Cross Rear / SHG Bed Axis)
600-65560	Lathe kits (MHG Compound Axis)

### **Mill Kits (Not Including Scale Bracket Kits)**

<i>Part Number</i>	<i>Description</i>
600-65480	Quill Kit (MHG)

# NEWALL


PART NUMBER CONFIGURATION FOR

## EXTENSION CABLES

for use with

**SHG-VP, SHG-VS & MHG-VP**

SERIES INCREMENTAL LINEAR ENCODERS



STANDARD SPECIFICATIONS SHOWN IN RED

# NEWALL


PART NUMBER CONFIGURATION FOR

## OUTPUT CABLES

for use with

**SCC-200**

SIGNAL CONVERTER



STANDARD SPECIFICATIONS SHOWN IN RED